





FITTAR




Smart Box

Quick start guide


1. What's in the box



Smart Box (incl. Mount)




Backside (Box)



Remote control




HDMI



Charger




Adapterplug



Batteries


2. Let's set it up

Step 1




Attach the adapterplug to the charger

Step 2




Plug the power cable into the Smart Box and into the power outlet

Step 3



Place the Smart Box on or near the TV
Preferably between 60-180 cm height (ideal: 80-120 cm)

Step 4



Plug the HDMI cable into the box and TV


3. Let's get connected

Wi-Fi connect

To connect to WiFi you have two options:

Option 1: QR code connection

Use your phone to generate a QR code online and connect to wifi.



Show a Wi-Fi QR code to the camera



Android: On your Android phone, through the current Wi-Fi connection, you can generate a QR code



iPhone: For iPhone, you can generate a free QR code online



Go to www.qr-code-generator.com on your phone and choose Wi-Fi



Enter your network and password and you will receive a QR code

Option 2: Remote connection

Use the remote to navigate to the WiFi network selection screen on the TV.



Enter Network Name...

Enter Password...

Enter the network name and password through the digital keyboard overlay. Press 'confirm' when the details are filled in.

4. Congrats, let's get started

You did it!

You can get started with all of our fun on demand work outs, campaigns and of course the exergames.

Was the installation unsuccessful?

Please contact us at **support@fittar.eu**

To learn more about all the features of the Smart Box and Playground, visit **www.fittar.eu/tutorials** for more information!

For general questions you can email us at: **info@fittar.eu**



FITTAR



Follow us on social media